


NUX Mighty Lite BT Update:

Please connect the USB cable (Micro B) to your PC and Mighty Lite BT, and follow the steps below.

1. Press and hold the TAP button, push the POWER button and turn ON the amplifier.
2. Run the NUX DFU Updater software, product name will appear on the screen. Click "Select File"
3. Click "Start Update" and do not power off the amp or turn the PC off until the update complete

You can see the update process on the updater software, and the amplifier lights will blink during the update. When it's done, turn OFF the amp and unplug the USB cable. Now you can run the amp again and it's ready to play!

1



2



3